


HD40A



product guide

features

- 8,818 lbs maximum load capacity
- 114'-10" maximum operating hook radius
- 101'-8" maximum hook height with jib set at 18 degrees
- 75'-6" maximum hook height with jib set at 0 degrees
- 18 different jib configurations
- Hoist speeds up to 213 ft/min with 2,205 lbs
- Trolley speeds up to 138 ft/min with max load
- Swing speeds up to 0.8 rpm with max load
- Manitowoc CraneCARE comprehensive support



contents

Outline
Dimensions

2

Outline
Dimensions

3

Rated Load
Charts

4

Rated Load
Charts

5

Mechanical
Data




6

Crane Care

7

outline dimensions

2





HD40A



outline dimensions

3



DJ105 / S125

Dimensions During Transport

Overall Length, (OL) =	50'-0"
Overhang, (OH) =	17'-5"
Maximum Overall Height, (MOH) =	11'-8"
Overall Width, (OW) =	8'-2"
Fifth Wheel to C.L. Rotation, (FWR) =	8'-2"
Axle Spacing, (AS) =	24'-5"

Weights During Transport (without cab)

Total Crane - With "A" & "B" Blocks	42,681 lbs
Weight under Fifth Wheel	19,312 lbs
Weight under Rear Axle	23,369 lbs
Weight of each "A" Block	4,740 lbs
Weight of each "B" Block	3,417 lbs
Permissible Ballast During Transport	9,480 lbs

DJ126M / S125

Dimensions During Transport

Overall Length, (OL) =	52'-2"
Overhang, (OH) =	17'-5"
Maximum Overall Height, (MOH) =	11'-10"
Overall Width, (OW) =	8'-2"
Fifth Wheel to C.L. Rotation, (FWR) =	8'-2"
Axle Spacing, (AS) =	24'-5"

Weights During Transport (without cab)

Total Crane - With "A" & "B" Blocks	48,281 lbs
Weight under Fifth Wheel	25,133 lbs
Weight under Rear Axle	23,149 lbs
Weight of each "A" Block	4,740 lbs
Weight of each "B" Block	3,417 lbs
Permissible Ballast During Transport	16,314 lbs

DJ80 / S120

Dimensions During Transport

Overall Length, (OL) =	50'-0"
Overhang, (OH) =	17'-5"
Maximum Overall Height, (MOH) =	11'-2"
Overall Width, (OW) =	8'-2"
Fifth Wheel to C.L. Rotation, (FWR) =	8'-2"
Axle Spacing, (AS) =	24'-5"

Weights During Transport (without cab)

Total Crane - With "A" & "B" Blocks	41,579 lbs
Weight under Fifth Wheel	18,585 lbs
Weight under Rear Axle	22,994 lbs
Weight of each "A" Block	4,740 lbs
Weight of each "B" Block	3,417 lbs
Permissible Ballast During Transport	9,480 lbs

DJ126M / S215M

Dimensions During Transport

Overall Length, (OL) =	54'-8"
Overhang, (OH) =	17'-10"
Maximum Overall Height, (MOH) =	12'-11"
Overall Width, (OW) =	8'-2"
Fifth Wheel to C.L. Rotation, (FWR) =	10'-10"
Axle Spacing, (AS) =	26'-8"

Weights During Transport (without cab)

Total Crane - With "A" & "B" Blocks	51,809 lbs
Weight under Fifth Wheel	22,708 lbs
Weight under Rear Axle	29,101 lbs
Weight of each "A" Block	4,740 lbs
Weight of each "B" Block	3,417 lbs
Permissible Ballast During Transport	16,314 lbs


DJ100 / S120

Dimensions During Transport

Overall Length, (OL) =	50'-0"
Overhang, (OH) =	17'-5"
Maximum Overall Height, (MOH) =	11'-8"
Overall Width, (OW) =	8'-2"
Fifth Wheel to C.L. Rotation, (FWR) =	8'-2"
Axle Spacing, (AS) =	24'-5"

Weights During Transport (without cab)

Total Crane - With "A" & "B" Blocks	42,042 lbs
Weight under Fifth Wheel	19,136 lbs
Weight under Rear Axle	22,906 lbs
Weight of each "A" Block	4,740 lbs
Weight of each "B" Block	3,417 lbs
Permissible Ballast During Transport	9,480 lbs



SL121 / S215M

Dimensions During Transport

Overall Length, (OL) =	46'-11"
Overhang, (OH) =	17'-10"
Maximum Overall Height, (MOH) =	13'-1"
Overall Width, (OW) =	8'-2"
Fifth Wheel to C.L. Rotation, (FWR) =	11'-2"
Axle Spacing, (AS) =	27'-0"

Weights During Transport (without cab)

Total Crane - With "A" & "B" Blocks	50,596 lbs
Weight under Fifth Wheel	20,944 lbs
Weight under Rear Axle	29,652 lbs
Weight of each "A" Block	4,740 lbs
Weight of each "B" Block	3,417 lbs
Permissible Ballast During Transport	16,314 lbs

SL122 / J215M

Dimensions During Transport

Overall Length, (OL) =	46'-11"
Overhang, (OH) =	17'-10"
Maximum Overall Height, (MOH) =	13'-1"
Overall Width, (OW) =	8'-2"
Fifth Wheel to C.L. Rotation, (FWR) =	11'-2"
Axle Spacing, (AS) =	27'-0"

Weights During Transport (without cab)

Total Crane - With "A" & "B" Blocks	50,486 lbs
Weight under Fifth Wheel	21,054 lbs
Weight under Rear Axle	29,873 lbs
Weight of each "A" Block	4,740 lbs
Weight of each "B" Block	3,417 lbs
Permissible Ballast During Transport	16,314 lbs

SL121 / J135

Dimensions During Transport

Overall Length, (OL) =	46'-11"
Overhang, (OH) =	18'-2"
Maximum Overall Height, (MOH) =	12'-8"
Overall Width, (OW) =	8'-2"
Fifth Wheel to C.L. Rotation, (FWR) =	11'-2"
Axle Spacing, (AS) =	26'-8"

Weights During Transport (without cab)

Total Crane - With "A" & "B" Blocks	48,810 lbs
Weight under Fifth Wheel	20,613 lbs
Weight under Rear Axle	28,197 lbs
Weight of each "A" Block	4,740 lbs
Weight of each "B" Block	3,417 lbs
Permissible Ballast During Transport	16,314 lbs

*Note: All dimensions are in feet
All weights in pounds


*Note: For all transport configurations the main body length,
(MBL) = 43'4".

HD40A



rated load charts

4



Jib Configuration: L35 with maximum hook reach of 114'-10" set at 0 degrees

Hook Reach (ft)	9'-6"	36'-9"	39'-4"	42'-8"	45'-11"	49'-3"	52'-6"	55'-9"	59'-1"	62'-4"	65'-7"	72'-2"	78'-9"	85'-4"	91'-10"	95'-2"	101'-8"	108'-3"	114'-10"
Trolley	Capacities (lbs)																		
SM/DM	8,818	8,818	8,146	7,385	6,746	6,195	5,732	5,324	4,971	4,663	4,376	3,902	3,516	3,186	2,910	2,789	2,568	2,381	2,205

Maximum Hook Height at Jib Tip: H = 75'-6"
Maximum Hook Height at Jib Foot: H = 68'-11"



Jib Configuration: L31 with maximum hook reach of 101'-8" set at 0 degrees

Hook Reach (ft)	9'-6"	40'-0"	42'-8"	45'-11"	49'-3"	52'-6"	55'-9"	59'-1"	62'-4"	65'-7"	72'-2"	78'-9"	85'-4"	91'-10"	95'-2"	101'-8"
Trolley	Capacities (lbs)															
SM/DM	8,818	8,818	8,157	7,452	6,856	6,349	5,908	5,512	5,170	4,861	4,332	3,902	3,549	3,241	3,109	2,866

Maximum Hook Height at Jib Tip: H = 74'-9"
Maximum Hook Height at Jib Foot: H = 68'-11"



Jib Configuration: L35 with maximum hook reach of 90'-3" set at 0 degrees

Hook Reach (ft)	9'-6"	38'-1"	39'-4"	42'-8"	45'-11"	49'-3"	52'-6"	55'-9"	59'-1"	62'-4"	65'-7"	72'-2"	78'-9"	85'-4"	90'-3"
Trolley	Capacities (lbs)														
SM/DM	8,818	8,818	8,422	7,628	6,978	6,415	5,930	5,512	5,148	4,828	4,542	4,045	3,638	3,307	3,086


Maximum Hook Height at Jib Tip: H = 74'-1"
Maximum Hook Height at Jib Foot: H = 68'-11"



Jib Configuration: L31 with maximum hook reach of 90'-3" set at 0 degrees

Hook Reach (ft)	9'-6"	38'-1"	39'-4"	42'-8"	45'-11"	49'-3"	52'-6"	55'-9"	59'-1"	62'-4"	65'-7"	72'-2"	78'-9"	85'-4"	90'-3"
Trolley	Capacities (lbs)														
SM/DM	8,818	8,818	8,422	7,628	6,978	6,415	5,930	5,512	5,148	4,828	4,542	4,045	3,638	3,307	3,086


Maximum Hook Height at Jib Tip: H = 74'-1"
Maximum Hook Height at Jib Foot: H = 68'-11"



Jib Configuration: L35 with maximum hook reach of 45'-11" set at 0 degrees

Hook Reach (ft)	9'-6"	45'-11"
Trolley	Capacities (lbs)	
SM/DM	8,818	8,818


Maximum Hook Height at Jib Tip: H = 71'-6"
Maximum Hook Height at Jib Foot: H = 68'-11"



Jib Configuration: L31 with maximum hook reach of 45'-11" set at 0 degrees

Hook Reach (ft)	9'-6"	45'-11"
Trolley	Capacities (lbs)	
SM/DM	8,818	8,818

Maximum Hook Height at Jib Tip: H = 71'-6"
Maximum Hook Height at Jib Foot: H = 68'-11"



Jib Configuration: L35 with maximum hook reach of 113'-2" set at 11 degrees

Hook Reach (ft)	9'-6"	64'-4"	72'-2"	82'-0"	88'-7"	98'-5"	105'-0"	113'-2"
Trolley	Capacities (lbs)							
SM	4,409	4,409	3,836	3,285	2,987	2,624	2,425	2,205


Maximum Hook Height at Jib Tip: H = 88'-7"
Maximum Hook Height at Jib Foot: H = 70'-2"



Jib Configuration: L31 with maximum hook reach of 100'-1" set at 11 degrees

Hook Reach (ft)	9'-6"	69'-11"	72'-2"	82'-0"	88'-7"	100'-1"
Trolley	Capacities (lbs)					
SM	4,409	4,409	4,255	3,649	3,329	2,866

Maximum Hook Height at Jib Tip: H = 86'-3"
Maximum Hook Height at Jib Foot: H = 70'-2"



Jib Configuration: L35 with maximum hook reach of 88'-7" set at 11 degrees

Hook Reach (ft)	9'-6"	65'-11"	72'-2"	82'-0"	88'-7"
Trolley	Capacities (lbs)				
SM	4,409	4,409	3,957	3,395	3,086


Maximum Hook Height at Jib Tip: H = 84'-0"
Maximum Hook Height at Jib Foot: H = 70'-2"

HD40A




rated load charts


5




Jib Configuration: L31 with maximum hook reach of 88'-7" set at 11 degrees									
Hook Reach (ft)	9'-6"	65'-11"	72'-2"	82'-0"	88'-7"				
Trolley	Capacities (lbs)								
SM	4,409	4,409	3,957	3,395	3,086				
Maximum Hook Height at Jib Tip: H = 84'-0"									
Maximum Hook Height at Jib Foot: H = 70'-2"									




Jib Configuration: L35 with maximum hook reach of 45'-3" set at 11 degrees									
Hook Reach (ft)	9'-6"	45'-3"							
Trolley	Capacities (lbs)								
SM	4,409	4,409							
Maximum Hook Height at Jib Tip: H = 76'-1"									
Maximum Hook Height at Jib Foot: H = 70'-2"									



Jib Configuration: L31 with maximum hook reach of 45'-3" set at 11 degrees									
Hook Reach (ft)	9'-6"	45'-3"							
Trolley	Capacities (lbs)								
SM	4,409	4,409							
Maximum Hook Height at Jib Tip: H = 76'-1"									
Maximum Hook Height at Jib Foot: H = 70'-2"									




Jib Configuration: L35 with maximum hook reach of 109'-11" set at 18 degrees									
Hook Reach (ft)	9'-6"	109'-11"							
Trolley	Capacities (lbs)								
SM	2,205	2,205							
Maximum Hook Height at Jib Tip: H = 101'-8"									
Maximum Hook Height at Jib Foot: H = 71'-5"									



Jib Configuration: L31 with maximum hook reach of 97'-5" set at 18 degrees									
Hook Reach (ft)	9'-6"	97'-5"							
Trolley	Capacities (lbs)								
SM	2,205	2,205							
Maximum Hook Height at Jib Tip: H = 97'-5"									
Maximum Hook Height at Jib Foot: H = 71'-5"									



Jib Configuration: L35 with maximum hook reach of 86'-3" set at 18 degrees									
Hook Reach (ft)	9'-6"	86'-3"							
Trolley	Capacities (lbs)								
SM	2,205	2,205							
Maximum Hook Height at Jib Tip: H = 94'-2"									
Maximum Hook Height at Jib Foot: H = 71'-5"									



Jib Configuration: L31 with maximum hook reach of 86'-3" set at 18 degrees									
Hook Reach (ft)	9'-6"	86'-3"							
Trolley	Capacities (lbs)								
SM	2,205	2,205							
Maximum Hook Height at Jib Tip: H = 94'-2"									
Maximum Hook Height at Jib Foot: H = 71'-5"									



Jib Configuration: L35 with maximum hook reach of 44'-0" set at 18 degrees									
Hook Reach (ft)	9'-6"	44'-0"							
Trolley	Capacities (lbs)								
SM	2,205	2,205							
Maximum Hook Height at Jib Tip: H = 80'-9"									
Maximum Hook Height at Jib Foot: H = 71'-5"									



Jib Configuration: L31 with maximum hook reach of 44'-0" set at 18 degrees									
Hook Reach (ft)	9'-6"	44'-0"							
Trolley	Capacities (lbs)								
SM	2,205	2,205							
Maximum Hook Height at Jib Tip: H = 80'-9"									
Maximum Hook Height at Jib Foot: H = 71'-5"									

HD40A




mechanical data

6

Function	Hoist Type	Speed vs Weight	2-part				4-part				Motor (hp)	Motor (kW)
			1st Gear	2nd Gear	3rd Gear	4th Gear	1st Gear	2nd Gear	3rd Gear	4th Gear		
Hoist	15 RPC 10	ft/min lbs	35 4,409	106 4,409	213 2,205		18 8,818	53 8,818	106 4,409		18	13
	15 LVF 10 Optional	ft/min lbs	16 4,409	89 4,409	141 2,756	174 2,205	8 8,818	44 8,818	71 5,512	87 4,409	18	13
Trolley	3 D2 V5	ft/min	69 to 138								3.2	2.4
Swing	RVF 2 30	rpm	0.8								3.5	2.6

Power Requirements: 480 V (+6% or -10%) 60 Hz measured at turn table.
Amperage: 15 LVF 10: 29 Amp (3 phase service with ground)
Amperage: 15 RPC 10: 29 Amp (3 phase service with ground)



Maximum In-Service Corner Force; F = 49,604 lbs
Maximum Out of Service Corner Force; F = 34,833 lbs

The weight of the machine with full jib and without load, ballast, or transport axles is 27,117 lbs

Warning Systems

Limit Moment Cut-Out – Prevents a moment that is more than +10%.

Warning

1. The operator must read and understand the owner's manual before operating this crane.
2. Positioning or operation of crane beyond areas shown is not intended or approved except where specified in owner's manual.
3. Practical working loads depend on supporting surface, wind, and other factors affecting stability such as hazardous surroundings, experience of personnel, and proper handling, all of which must be taken into account by the operator.

HD40A



CraneCARE

CraneCARE is Manitowoc's complete service and support program. Incorporated into this program are service training, immediate parts availability, professional field service, and technical support and documentation. CraneCARE is available for every one of the thousands of cranes operating all over the world.

That's dedication and devotion that you won't get anywhere else.

That's **CraneCARE**.

Service Training

A certified Manitowoc service specialist works with you in your training facility or in the field to ensure that you know how to achieve maximum performance, dependability, and years from your cranes.

A reputable Manitowoc Service technician comes to you to provide valuable training to all distributors on the crane's LMI system.

Parts Availability

Genuine Manitowoc replacement parts may be obtained through your MCG distributor on a regular basis.

Field Service

Factory-trained service experts are always ready to help maintain your crane's peak performance.

For a worldwide listing of dealer locations, please consult our website at: www.manitowoccranes.com.

Technical Support

Manitowoc's dealer network and factory personnel are available 24 hours a day, 7 days a week, 365 days a year to answer your technical questions and more. **7**

For a worldwide listing of dealer locations, please consult our website at: www.manitowoccranes.com.

Technical Documentation

Manitowoc boasts an extensive, easy-to-understand library of documentation.

A complete set of Operator's parts and service manuals are included with each crane.

Additional copies are available through your Authorized Manitowoc Distributor.

HD40A





Manitowoc Crane Group - Americas

Manitowoc, Wisconsin Facility
Tel: [Int + 001] 920 684 6621
Fax: [Int + 001] 920 683 6277
Shady Grove, Pennsylvania Facility
Tel: [Int + 001] 717 597 8121
Fax: [Int + 001] 717 597 4062

Manitowoc Crane Group - EMEA

Europe Middle East & Africa
Tel: [Int + 33] (0) 4 72 18 20 20
Fax: [Int + 33] (0) 4 72 18 20 00

Manitowoc Crane Group - UK

Europe Middle East & Africa (Parts & Service)
Tel: [Int + 44] (0) 191 565-6281
Fax: [Int + 44] (0) 191 564-0442

Manitowoc Crane Group - Germany

(Sales, Parts & Service)
Tel: [Int + 49] (0) 2173 8909-0
Fax: [Int + 49] (0) 2173 8909-30

Manitowoc Crane Group - France

France & Africa (Sales, Parts & Service)
Tel: [Int + 33] (0) 1 303-13150
Fax: [Int + 33] (0) 1 303-86085

Manitowoc Crane Group - Netherlands

(Sales, Parts & Service)
Tel: [Int + 31] (0) 76 578 39 99
Fax: [Int + 31] (0) 76 578 39 78

Manitowoc Crane Group - Italy

Italy & Southern Europe (Sales, Parts & Service)
Tel: [Int + 39] (0) 331 49 33 11
Fax: [Int + 39] (0) 331 49 33 30

Manitowoc Crane Group - Portugal

Portugal & Spain (Sales, Parts & Service)
Tel: [Int + 351] (0) 22 968 08 89
Fax: [Int + 351] (0) 22 968 08 97

Manitowoc Crane Group - Singapore

Asia/Pacific excl China (Sales, Parts & Service)
Tel: [Int + 65] 6861-7133
Fax: [Int + 65] 6862-4040 / 4142

Manitowoc Crane Group - Shanghai

China (Sales, Parts & Service)
Tel: [Int + 86] (0) 21-64955555
Fax: [Int + 86] (0) 21-64852038

Manitowoc Crane Group - Beijing

China (Sales, Parts & Service)
Tel: [Int + 86] (0) 10 646-71690
Fax: [Int + 86] (0) 10 646-71691

Manitowoc Crane Group - Middle East

(Sales)
Tel: [Int + 971] (0) 4 348-4478
Fax: [Int + 971] (0) 4 348-4478
(Parts & Service)
Tel: [Int + 973] (0) 9 660-899
Fax: [Int + 973] (0) 2 707-740

Distributed By:



www.manitowoccrane.com

Constant improvement and engineering progress make it necessary that we reserve the right to make specification, equipment, and price changes without notice. Illustrations shown may include optional equipment and accessories, and may not include all standard equipment.